

RLDF1510 Pharmacy & Vaccine Refrigerator



Powered by the unique IntelliCold™ Controller, this pharmacy refrigerator has superior temperature uniformity and energy consumption, plus extra functions designed to store temperature sensitive pharmaceuticals in optimum conditions and assist busy professionals with regulatory requirements.



The simple to use four button interface is clearly labelled and allows minimum/maximum temperatures to be displayed at the touch of a button. It also shows clearly which alarm is active and why, making remedial action easy. A clear LED display shows the internal temperature of the fridge to one decimal place.



For objective and accurate record keeping, once the warranty is registered, a complimentary SD card will be sent which can be used to download all the temperature data stored by the controller. This can also be used to extract short term data if, for example, there is a suspected temperature incursion; data can be downloaded and used to prove the viability of the contents. Extra reassurance is provided by controller battery back up which can record and alarm in the event of a mains power failure.

The free standing RLDF1510 can be fitted with up to six drawers to help keep stock tidy. These drawers can be retro fitted and purchased individually.

We are confident that this pharmacy refrigerator will provide you with many years of fault free service. However, for extra peace of mind your RLDF1510 comes complete with a FREE 5 year parts and labour warranty!*



Part Number	RLDF1510
Capacity (Litres)	430
Style	Free standing
Exterior Dimensions (HxWxD)	1860 x 600 x 700mm
Interior Dimensions (HxWxD)	1525 x 520 x 510mm
Energy Consumption	1.1 kWh/24h
Operating Temperature	+5°C
Interior Construction	Painted Corrosion proof Aluminium
Exterior Construction	Powder Coated Steel
Shelves	6
Internal Drawers Available	✓
Door Style	Solid
Door Hinging	Right (can be reversed at time of manufacture)
Door Lock	✓
Access Port	✓
Digital Temperature Control	✓
Digital Temperature Display	✓
Internal Light	✓
High/Low Temperature alarm	✓
Minimum/Maximum Temperature Recording	✓
Up to 13 months temperature data storage	✓
Door Open alarm	✓
Mains Failure alarm	✓
Alarm Battery Back-Up	✓
Off cycle auto defrost	✓
Fan Assisted Cooling	✓
Remote Alarm Contacts	✓
Eco Friendly Refrigerant	✓
Ammonia Free	✓
DH Green Book, RPS/ GPhC, NaTHNaC and RCVS Guidelines compliant	✓

* Terms and conditions apply, please visit the web site