

RLDG0210 Glass Door Pharmacy & Vaccine Refrigerator



Powered by
IntelliCold™
Technology

Powered by the unique IntelliCold™ Controller, this pharmacy refrigerator has superior temperature uniformity and energy consumption, plus extra functions designed to store temperature sensitive pharmaceuticals in optimum conditions and assist busy professionals with regulatory requirements.



The simple to use four button interface is clearly labelled and allows minimum/maximum temperatures to be displayed at the touch of a button. It also shows clearly which alarm is active and why, making remedial action easy. A clear LED display shows the internal temperature of the fridge to one decimal place.

For objective and accurate record keeping, once the warranty is registered, a complimentary SD card will be sent which can be used to download all the temperature data stored by the controller. This can also be used to extract short term data if, for example, there is a suspected temperature incursion; data can be downloaded and used to prove the viability of the contents. Extra reassurance is provided by controller battery back up which can record and alarm in the event of a mains power failure.

The RLDG0210 is a compact refrigerator, ideal for consulting rooms or wards which can be wall mounted on integral brackets.

We are confident that this pharmacy refrigerator will provide you with many years of fault free service. However, for extra peace of mind your RLDG0210 comes complete with a FREE 5 year parts and labour warranty!*

* Terms and conditions apply, please visit the web site



Part Number	RLDG0210
Capacity (Litres)	66
Style	Benchtop/wall mounted
Exterior Dimensions (HxWxD)	720 x 450 x 485mm
Interior Dimensions (HxWxD)	509 x 360 x 335mm
Energy Consumption	0.63 kWh/24h
Operating Temperature	+5°C
Interior Construction	Painted Corrosion proof Aluminium
Exterior Construction	Powder Coated Steel
Shelves	3
Internal Drawers Available	x
Door Style	Glass
Door Hinging	Right
Door Lock	✓
Digital Temperature Control	✓
Digital Temperature Display	✓
Internal Light	✓
High/Low Temperature alarm	✓
Minimum/Maximum Temperature Recording	✓
Up to 13 months temperature data storage	✓
Door Open alarm	✓
Mains Failure alarm	✓
Alarm Battery Back-Up	✓
Off cycle auto defrost	✓
Fan Assisted Cooling	✓
Remote Alarm Contacts	✓
Eco Friendly Refrigerant	✓
Ammonia Free	✓
DH Green Book, RPS/ GPhC, NaTHNaC and RCVS Guidelines compliant	✓