

RLWF1018 Free Standing Ward Refrigerator

Part Number	RLWF1018
Capacity (Litres)	340
Style	Free Standing
Exterior Dimensions (HxWxD)	1500 x 600 x 700mm (+40mm for handle)
Interior Dimensions (HxWxD)	1358 x 480 x 500mm
Energy Consumption	1.52Kw/24hrs
Operating Temperature	+3°C
Temperature Range	+0°C to +5°C
Interior Construction	Powder Coated Steel
Exterior Construction	Powder Coated Steel
Shelves	6
Net Weight (kg)	79
Door Style	Solid
Door Hinging	Right (can be reversed at time of manufacture)
Door Handle	✓
2 Rollers and 2 levelling feet	✓
Self Closing Door	✓
Door Lock	✓
Digital Temperature Control	✓
Digital Temperature Display	✓
Internal Light	✓
High/Low Temperature Alarm	✓
Door Open Alarm	✓
Off Cycle Auto Defrost	✓
Fan Assisted Cooling	✓
Access Port	✓
Low GWP Refrigerant	✓
Ammonia Free	✓
1 Year Warranty (UK only)	✓



Designed for the secure storage of food and beverages this free standing ward refrigerator features an internal fan for even temperature distribution, eliminating 'hot' and 'cold' spots, a bright energy saving LED internal light and a door lock to prevent unauthorised access.



This ward refrigerator has a digital temperature display featuring a set point display. We will, however, factory set your ward refrigerator to have a set point of +3°C which is an ideal temperature to prevent the multiplication of bacteria and stop the contents entering the 'danger zone' for food storage of 5°C to 8°C. This fridge also features a visual and audio door open alarm plus a high and low temperature alarm for extra safety.

There are 6 full size adjustable shelves so it's easy to make sure all food has adequate air flow and can fit in the fridge. It also comes fitted with a door handle, minimising wear and tear on the gasket when opening and providing added convenience.

As you would expect this is a quality refrigerator from Labcold and designed specifically for food storage. It has been engineered to be robust enough to easily cope with life on a busy ward, but for extra peace of mind your Labcold Ward Refrigerator comes complete with a comprehensive one year parts and labour warranty*.



*Terms and conditions apply, please visit the web site

01256 705 570

www.labcold.com

